

# Instructions

## WARNING

See the *Important Safety and Product Information* guide in the GPS product box for product warnings and other important information.

Do not use a sharp object to remove user-replaceable batteries.

Contact your local waste disposal department to properly recycle the batteries. Perchlorate Material — special handling may apply. See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate).

## Separating the Sensor from the Clip

- 1 Press the tab (1) on the clip.



- 2 Lift and separate the sensor (2) from the clip.

## Installing the Battery

- 1 Locate the circular battery cover (1) on the back of the device.



- 2 Turn the cover counter-clockwise until it is loose enough to remove.
- 3 Remove the cover.
- 4 Place the battery into the cover with the positive side facing the inside of the cover.
- 5 Replace the cover by aligning the dots (2) and rotating clockwise.

## Installing the Device

### NOTICE

The sensor should be attached to a secure strap or loop.

You can also place the sensor in an exterior jacket pocket.

- 1 Place the clip behind the strap or loop.
- 2 Align the arrow on the sensor and clip.
- 3 Snap the sensor into the clip.

## Pairing the Sensor with your Device

Before you can view temperature data on your compatible GPS device, you must pair the sensor with the device.

This procedure contains instructions for the fenix. If you have another compatible device, see your owner's manual.

- 1 Move 10 m away from other ANT-sensors.
- 2 Turn on the device.
- 3 Bring the device within range (9.8 ft. or 3 m) of the sensor.
- 4 Select the Orange key.
- 5 Select Setup > **ANT** Sensor > Tempe > New Search.

When the tempe is paired, the fenix displays temperature data from the tempe instead of using the internal temperature sensor. For more information, see the *fenix Owner's Manual*.

## Tips

- Place the sensor where it is exposed to ambient air.
- Avoid locations where sunlight, body heat, or other conflicting hot/cold sources could affect the sensor.

## Specifications

|                             |   |
|-----------------------------|---|
| Battery type                | User-replaceable CR2032, volts                |
| Battery life                | Up to 1 year                                  |
| Water resistance            | Water resistant to 32.9 ft. (10 m)            |
| Operating temperature range | From -4°F to 140°F (from -20°C to 60°C)       |
| Radio frequency/ protocol   | 2.4 GHz ANT+ wireless communications protocol |

## FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class **B** digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet that is on a different circuit from the GPS unit.
- Consult the dealer or an experienced radio/ TV technician for help.

This product does not contain any user-serviceable parts. Repairs should only be made by an authorized service center. Unauthorized repairs or modifications could result in permanent damage to the equipment, and void your warranty.